



Decent Models

38 Bafford Lane, Charlton Kings,

Cheltenham, Glos. GL53 8DW

Tel. (0242) 515605

CALEDONIAN RAILWAY GOODS BRAKE VAN DECENT MODELS KIT NO. 5



Design based on C.R. drawing No. 4938,
dated 6 July 1886. (OPC drawing No. 11942)

INSTRUCTIONS

Before you begin, read the instructions all the way through.

CHASSIS

1. Turn the fret over and gently impress the rivet detail with a not-too-sharp tool, on the rear of the solebar overlays (F). Note, some practice rivets are marked on the fret, so you can determine the best pressure - see piece marked 'N'.



2. Remove floor unit 'A' file tags off flush, bend as in diagram (1). Bend down wheel-unit supports, 2 at one end, 4 at the other. Strengthen with solder.
3. Remove 'B' & 'C', fold as in diagram (2). Take care not to distort brake-gear 'D' & 'E' when removing 'B' & 'C'. Note when you detach these parts carefully store handrail adjacent to it, on the fret, also the wee bunch of lamp-irons. Before folding 'B' & 'C' file all attachment tags off flush. Now fit the wheels.